



because clean matters.

TELEVISION TUNERS

Removing oxides as well as common grit and gum is easy and safe with L&R Ultrasonic Cleaners and the proper L&R Cleaning Solutions. After removing tuners from television.

Simply-

1. Fill tank and Auxiliary Pans with enough of the proper solution to totally immerse the television tuners.
2. Place tuner in Basket, lower into main tank filled with #112 Ammoniated Ultrasonic Instrument Cleaning Solution or #222 Non-Ammoniated Ultrasonic Instrument Cleaning Solution.
3. Cavitate 3-5 minutes. Remove and drain.
4. Place Basket in an Auxiliary Pan filled with Instrument Rinsing Solution and place Auxiliary Pan in main tank.
5. Cavitate 3-5 minutes. Remove, drain and air dry.
Note: Some silver contact points may require a drop of L&R Silver Contact Cleaner to remove tarnish.

EQUIPMENT NEEDED:

Machines, Accessories*: Q140, Q210, Q360 Ultrasonic Cleaning System with Timer, Basket and Auxiliary Pan.

Solutions: #112 Ammoniated Ultrasonic Instrument Cleaning Solution (PC188); or #222 Non-Ammoniated Ultrasonic Instrument Cleaning (PC191); or Instrument Rinsing Solution(PC194); or L&R Silver Contact Cleaner (PC 209).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

