



*because clean matters.*

## DEMAND REGISTERS

Oil residues, gum sediments and grease are easily removed from demand registers adding years of life and accuracy. Non-abrasive, cleaning with L&R Ultrasonic Cleaning Systems saves hours of hand cleaning.

Simply-

1. Place in basket and immerse in main tank containing Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Heavy Duty Solvent Free Degreaser Concentrate at the recommended dilution rates (see product label).
2. Cavitate 3-7 minutes.
3. Rinse well under warm running water.
4. Air dry or dry using warm air (forced air dryer).

### EQUIPMENT NEEDED:

Machines, Accessories\*: Q140 Ultrasonic Cleaning System with Timer, Optional Heater\*\*, Auxiliary Pans, Basket.

Solution: Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (Product Code 110); SF-50 Heavy Duty Solvent Free Degreaser Concentrate (Product Code 071).

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning. Please contact an L&R Sales Specialist to determine your cleaning needs.

