



because clean matters.

FISHING REELS

Acid soaks and abrasive hand cleaning are a thing of the past now that L&R Ultrasonic Cleaning Systems are available.

Simply-

1. Place disassembled parts in Basket and immerse in tank containing Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Solvent-Free Degreaser Concentrate at the recommended dilution (see product label).
2. Cavitate 3-7 minutes, drain in basket.
3. Rinse well under warm tap water.
4. Air dry or dry using forced warm air.
5. Lubricate and reassemble.

If salt water corrosion is a problem, cavitate in L&R Hydro-Sonic Concentrate (Ammoniated) without heat and rinse with water. Dry thoroughly, lubricate and reassemble.

EQUIPMENT NEEDED:

Machines, Accessories*: Q90, Q140 Ultrasonic Cleaning System with Timer, Optional Heater**, Basket, Auxiliary Pan.

Solutions: Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (PC110); SF-50 Solvent-Free Degreaser Concentrate (PC 71); Hydro-Sonic Cleaning Solution Concentrate (PC 201).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

**If using Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated or SF-50 Solvent Free Degreaser.

