



*because clean matters.*

## FUEL FILTERS (AIRCRAFT)

Soaking fuel filters in highly flammable Stoddard Solvent is DANGEROUS and time consuming. A better approach is to use an L&R Ultrasonic Cleaning System.

Simply-

1. Place Basket containing filters into tank filled with Hydro-Sonic Cleaning Solution Concentrate or Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated at the recommended dilution (see product labels).
2. Cavitate 3-9 minutes.
3. Remove and rinse well under warm tap water.
4. Air dry or dry using warm forced air.
5. Purge with fuel to displace traces of water before using.

### EQUIPMENT NEEDED:

Machines, Accessories\*: Q210 Ultrasonic Cleaning System with Timer, Auxiliary Pan and Basket (optional heat.)

Solutions: Hydro-Sonic Cleaning Solution Concentrate (P C 201); Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (PC 110).

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

\*\*Please contact an L&R Sales Specialist to discuss appropriate size machine for cleaning of multiple parts at one time

