



because clean matters.

GOLD AND JEWELRY

Rather than boiling, steaming, and brushing polishes, flux, solder residue, and rouges etc. from just-manufactured jewelry, you can safely and quickly clean with ultrasonic equipment from L&R.

Simply-

1. Place rack of rings (or other jewelry) into an approximately sized L&R Ultrasonic Cleaner and cover with proper dilution of Ellanar Jewelry Cleaner Concentrate, PowerClean Heavy Duty Jewelry Cleaner Concentrate or PrepClean Buffing Compound Remover (see label for typical dilutions).
2. Cavitate 5-10 minutes.
3. Rinse with water or steam.
4. See them gleam.

EQUIPMENT NEEDED:

Machines, Accessories*: Q360, Q650 or 4000 Series Ultrasonic Cleaning System of appropriate size, with Timer, Optional Heater**, Basket.

Solutions: Ellanar Jewelry Cleaner Concentrate (PC170); Power Clean Investment Remover (PC183); Power Clean Heavy Duty Jewelry Cleaner Concentrate (PC 184); PrepClean Plus Buffing Compound Remover with inhibitor (PC104); PrepClean Buffing Compound Remover (PC 078).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

**Note: Do not use internal heater when using Ellanar Jewelry Cleaner Concentrate, Ammoniated, as this will cause release of excessive ammonia.

