



because clean matters.

LAPIDARY, GEMS, ROCKS, MINERALS

Gems, rocks, antiques, minerals, fossils, and jewelry all have one thing in common they must be clean to be appreciated. Non-abrasive cleaning is the answer with an L&R Ultrasonic Cleaning System.

Simply-

1. Place Basket of specimens into tank containing proper dilution of Ellanar Jewelry Cleaner Concentrate (1 part cleaner: 7 parts water).

2. Cavitate 5-10 minutes.

3. Remove, rinse thoroughly with water and dry.

4. Notes:

Keep tank bottom free of silt, sediment and heavy specimens.
Acidic solutions must be used in glass Beakers. Do not put acid solutions directly in tank.

EQUIPMENT NEEDED:

Machines, Accessories*: Q90, Q360 or appropriate sized Ultrasonic Cleaning System to match volume and size of specimens: Basket, Positioning Cover, Beakers, Auxiliary Pans, Optional Heater.

Solution: Ellanar Jewelry Cleaner Concentrate (PC170).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

