



because clean matters.

LENSES

(after grinding and buffing)

After grinding and buffing lenses, but before heat treating for break resistance, insure yourself against any foreign residue being burned into the lenses. L&R Ultrasonic Cleaning Systems offer the most complete cleaning possible.

Simply-

1. Fill tank 1/2 to 3/4 full with Optical Cleaning Solution.
2. Place lenses in lens holder and immerse in solution. Cavitate for 2-3 minutes.
3. Remove, rinse thoroughly in water.
4. Dry thoroughly.

EQUIPMENT NEEDED:

Machines, Accessories*: Q90 Ultrasonic Cleaning System with Timer, Optional Heater, Auxiliary Pan, Basket.

Solutions: Optical Cleaning Solution Concentrate (PC 216).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

