



because clean matters.

MOBILE COMMUNICATION SETS

3-Way radios, handsets, walkie-talkie sets, etc. need no longer be sent to the manufacturer for rehabilitation. Dirt, dust, rust, and oxidation can be removed quickly, safely, and thoroughly with an L&R Ultrasonic Cleaning System.

Simply-

1. Remove housing before cleaning.
2. Place entire set into Basket and put into tank #1 containing #222 Non-Ammoniated Ultrasonic Instrument Cleaning Solution.
3. Cavitate 4 minutes. Lift out and let drain (60 seconds).
4. Immerse Basket into tank #2 containing L&R Instrument Rinsing Solution.
5. Cavitate 4 minutes. Lift out and drain. Air dry.
6. Test and reinstall.

EQUIPMENT NEEDED:

Machines, Accessories*: Q210, Q360 or Ultrasonic Cleaning Systems, Timer, Auxiliary Pan, Basket.

Solutions: #222 Non-Ammoniated Ultrasonic Cleaning Solution (PC191); Instrument Rinsing Solution (PC194).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

