



because clean matters.

TELEPHONE HOUSINGS (plastic outside case)

Rather than wiping and scrubbing with harsh solutions and solvents to restore a bright and presentable outside case for reconditioned telephone assemblies, you can quickly and thoroughly restore them to a "like-new" condition by using ultrasonic cleaning methods from L&R.

Simply-

1. Place Basket of housings in first tank containing #222 Non-Ammoniated Ultrasonic Instrument Solution or a heated solution of SF-1 Solvent-Free Degreaser Concentrate, and cavitate for 10-12 minutes.
2. Lift Basket, let drain. If using #222, place in second tank containing Instrument Rinsing Solution. Cavitate for 6 minutes. If using SF-1 Solvent-Free Degreaser Concentrate, rinse with warm water.
3. Remove and dry -- blow off excess solution.

EQUIPMENT NEEDED:

Machines & Accessories*: Q360, Q650 or 4000 Series Ultrasonic Cleaning Systems with Timer, Optional Heater if using SF-1 Solvent-Free Degreaser, Auxiliary Pan, Basket or Wash and Rinse Kits.

Solutions: SF-1 Solvent-Free Degreaser Concentrate (PC201) or #222 Non-Ammoniated Ultrasonic Instrument Solution (PC191); Instrument Rinsing Solution (PC194).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

