



L&R Manufacturing Company

577 Elm Street, P.O. Box 607, Kearny, New Jersey 07032-0607 USA

Phone: 201-991-5330, Fax: 201-991-5870

E-mail: info@LRultrasonics.com, www.LRultrasonics.com

Corona Wire Assembly Cleaning

Rather than wiping each wire manually with a cotton swab and alcohol, which is labor intensive and yields inconsistent results, simply-

1. Place assemblies on rack, or in basket, in a horizontal position and place in an L&R heated ultrasonic cleaning system of suitable size containing a solution of 2 ounces of Prep Clean Buffing Compound Remover Concentrate per gallon of 130°-140°F water. Clean for 2-3 minutes.
2. Remove rack or basket, let drain and rinse with hot water.
3. Remove and dry with heat gun or drying oven.

EQUIPMENT NEEDED:

Machines, Accessories*: Q210, Q255, Q310, S200 or S310 Ultrasonic Cleaning System with Timer, Optional Heater, Rack or Basket.

Solutions: Prep Clean Buffing Compound Remover Concentrate (Product Code 078).

*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.