



## APPLICATION BULLETIN #9A

### ELECTRIC DEMAND METERS

Oil residues, gum sediments and grease are easily removed from electric meters adding years of life and accuracy. Non-abrasive cleaning with L&R Ultrasonic Cleaning Systems save hours of hand cleaning.

Simply-

1. Place in Basket and immerse in tank 2/3 full containing Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated, or SF-50 Solvent-Free Heavy Duty at the recommended dilution rates (see product labels).
2. Cavitate 5-10 minutes.
3. Rinse well under warm tap water.
4. Air dry or dry using warm air (forced air dryer) or compressed air.

#### EQUIPMENT NEEDED:

Machines, Accessories\*: Q140 Ultrasonic Cleaning with Timer, Optional Heater\*\*, Cover, Basket

Solution: Hydro-Sonic Cleaning Solution Concentrate Non-Ammoniated (PC110)  
SF-50 Heavy Duty Solvent-Free Degreaser Concentrate (PC071)

\*Recommended Ultrasonic Cleaning System varies as to internal tank dimensions and volume of required cleaning.

Confirm meter is properly sealed prior to cleaning.



*because clean matters*

L&R Manufacturing Company  
577 Elm Street, PO Box 607  
Kearny, NJ 07032-0607 USA  
Tel: 201.991.5330 Fax: 201.991.5870  
[www.LRultrasonics.com](http://www.LRultrasonics.com) [info@LRultrasonics.com](mailto:info@LRultrasonics.com)